

# RC10B6.3DとB6.3 Team Kit Instruction Manual のお詫びと訂正

このたびは、RC10B6.3DとB6.3 Team Kitをご購入いただきまして、誠にありがとうございます。

本商品のInstruction Manualに誤記がありましたので、お詫び申し上げますとともに以下のように訂正いたします。

- ◆RC10B6.3Dのみ→ 13ページ、Bag7 Step1のボールスタッドワッシャー「5.5x2.0mm」から、『5.5x1.0mm』（オレンジ色付箇所）に変更
- ◆RC10B6.3Dのみ→ 15ページ、Bag8 Step2のフロントキャンバーターンバックルの長さ「26.9mm」から『22.60mm』（オレンジ色付箇所）に変更
- ◆RC10B6.3DとB6.3共通→ 15ページ、Bag9 Step1の赤丸部分(91495)を追加

## ◆RC10B6.3Dのキットのみ

13

### :: Bag 7 - Step 1

**91047 Heavy-duty Ballstud, 6mm**

**#1596 thread lock**

**31383 Ballstud Washers, 5.5x2.0mm, blue**

**31382 Ballstud Washers, 5.5x1.0mm, blue**

**92179 B6.2 Rear Hub Inserts**

**92180 Rear Hub Link Mounts**

**91857 B6.2 Rear Hubs**

**#1596 thread lock**

**89202 M3 x 12mm BHCS**

**Build x2 (right and left side)**

Rear Axle Height			
↑ 3	0 ↓	3 ↑	+3mm
↑ 2	1 ↓	2 ↑	+2mm Kit Setup
↓ 2	1 ↑	1 ↑	+1mm
↓ ε	0 ↑	0 ↑	+0mm

## ◆RC10B6.3Dのキットのみ

15

### :: Bag 8 - Step 2

**91722 Ball Cup**

**91723 Turnbuckle 3x48mm**

**91722 Ball Cup**

**Front Camber Turnbuckle 22.60mm**

**Build x2 (right and left side)**

**Racers Tip:**  
Use black grease (#6588) on the threads of the turnbuckles for easier ball cup installation!

**! Orient the notch to the left throughout the car. It indicates which end has the left hand threads!**

## ◆RC10B6.3DとRC10B6.3の両キット共通

15

### :: Bag 9 - Step 1

**91895 FT 12mm V2 Shock Piston, 2mm [2x1.5] (front)**

**31510 M2 x 4mm BHCS**

**89278 2.5mm Washer**

**91896 FT 12mm V2 Shock Piston, 2mm [2x1.6] flat (rear)**

**91615 V2 3 x 21 Shock Shaft TiN (front)**

**91619 V2 3 x 27.5 Shock Shaft TiN (rear)**

**91480 12x23mm V2 Shock Bodies (front)**

**91481 12x27.5mm V2 Shock Bodies (rear)**

**91493 X-Ring**

**91495 V2 Shock Spacer**

**91495 V2 Shock Hat Bushing**

**91491 12mm Shock Cap O-Ring**

**31327 VCS3 Shock Bottom Cap O-Ring**

**31327 VCS3 Shock Bottom Cap**

**#1105 green slime**

**! Mount the shock pistons with the number facing up!**

**! Lightly rub shock oil on the o-ring before installation!**

**Racers Tip:**  
Coating the o-rings with green slime (#1105) helps seal & reduce o-ring swell! **Green slime not included in kit!**

**Racers Tip:**  
Use a marker over the numbers on the pistons to make them easily visible!